



1-5



Electrak[®]
INDUSTRIAL TRACTOR

OPERATOR'S MANUAL

GENERAL  ELECTRIC

MODEL NO. <input type="text"/>	SERIAL NO. <input type="text"/>
TRACTOR WT. - 600 LBS.	BATTERY TYPE - E0583
BATTERY WT. - 360 LBS.	AMP. HRS. - 170 @ 5 HRS.
GROSS WT. - 960 LBS.	AMP. HRS. MAX. - 220
DRAWBAR PULL - 900 LBS.	VOLTAGE - 36 VDC



TYPE E INDUSTRIAL TRACTOR
PAT. NO. D. 222,692 - OTHERS PENDING.
MADE IN SCHENECTADY, N.Y., U.S.A.

GENERAL  ELECTRIC



Contents

	Page
Introduction	1
Warranty Registration	1
Plug-In . . . the key to automatic refueling	1
Safety Practices	2
Operation	2
Attachments	4
Tractor Controls	5
Safety Interlocks	8
Power Pack Care and Charging	12
Lubrication	15
Service and Maintenance	16
Storage	17
Periodic Service Chart	18
Specification Chart	18
Troubleshooting Checklist	19
Warranty	Back Cover

Ⓣ TRADEMARK

This manual does not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purpose, the matter should be referred to your authorized ELEC-TRAK tractor dealer.

