

GENERAL ELECTRIC

OUTDOOR
POWER EQUIPMENT
OPERATION

GENERAL ELECTRIC COMPANY, CORPORATIONS PARK, BUILDING 702,
SCHENECTADY, NEW YORK 12305 Phone (518) 374-2211

January 9, 1974

TO: HOLDERS OF ELEC-TRAK TRACTOR PARTS CATALOGS

SUBJECT: Revision of Parts Catalog, GEF-4374

The attached material updates your Elec-Trak tractor Parts Catalog to cover parts replacement on additional accessories.

Update your Parts Catalog as follows:


1. Remove the title page and Contents pages from the front of your book and discard them.
2. Insert the new title page, and Contents pages in place of the sheets removed in step 1.
3. Remove the first page of the ACCESSORIES section and replace it with the new page 16-1/16-2 furnished.
4. Remove and discard all material from page 16-65 to the end in the ACCESSORIES section.
5. Insert pages 16-65 through 16-125 as the last pages of the ACCESSORIES section.

Your Parts Catalog is now up to date. If you have any questions, please let us know.

Sincerely yours,

William A. Podoba

W. A. Podoba
Manager, Dealer Service






Electrak

Tractor



Electrak

TRACTOR PARTS CATALOG



General Electric Company
Outdoor Power Equipment Operation
Corporations Park, Bldg. 702
Schenectady, N. Y. 12345

GENERAL  ELECTRIC

CONTENTS

Section		Page
1	E20 Tractor Parts	1-1
	Body Components	1-3
	Dash Components, E20AA - E20DA	1-5
	Dash Components, E20EA	1-7
	Electrical Components, E20AA - E20DA	1-9
	Electrical Components, E20EA	1-11
	Speed Control	1-13
2	E15 Tractor Parts	2-1
	Body Components	2-3
	Dash Components, E15AA - E15GA	2-5
	Dash Components, E15HA	2-7
	Electrical Components, Upper Control Panel, E15AA - E15GA	2-9
	Electrical Components, Lower Control Panel, E15AA - E15GA	2-11
	Electrical Components, E15HA	2-13
	Speed Control	2-15
3	E12s Tractor Parts	3-1
	Body Components	3-3
	Dash Components	3-5
	Electrical Components, Upper Control Panel	3-7
	Electrical Components, Lower Control Panel	3-9
	Speed Control	3-11
4	E12 Tractor Parts	4-1
	Body Components	4-3
	Dash Components, E12 CA, DA, HA, JA	4-5
	Electrical Components, Upper Control Panel, E12CA, DA, HA, E12M EA	4-7
	Electrical Components, E12JA	4-9
	Speed Control	4-11
5	E12M Tractor Parts	5-1
	Body Components	5-3
	Dash Components	5-5
	Electrical Components, E12CA, DA, HA, E12MEA	5-7
	Speed Control	5-9
6	E8 and E10 Tractor Parts	6-1
	Body Components	6-3
	Front Battery Compartment, E8M, E8HD	6-5
	Front Battery Compartment, E10M	6-7
	Dash Components	6-9
	Electrical Components	6-11
	Rear Battery Compartment, E10M	6-13
	Rear Battery Compartment, E8M	6-15
	Undercarriage Components, E8M AA - CA, E10M AA - CA	6-17
	Undercarriage Components, E8DA, EA, E10DA	6-19
	Drive Assembly	6-21
7	Rear Battery Compartment	7-1
	Rear Battery Compartment, Large Frame	7-3
8	Chargers	8-1
	Charger for E20, E15, E12s, E12, E12M	8-3
	Charger for E8M and E10M	8-5
9	Lifts	9-1
	Front Lift, E20, E15, E12s, and E12	9-3
	Lift, E12M	9-5
	Lift, E8M and E10M	9-7

