



Electrak[®] ELECTRIC TRACTOR

**CHECK TIRE PRESSURE
BEFORE OPERATING**

FRONT 16 PSI

REAR 10 PSI

Before using ...

Read the operating instructions and
use and care recommendations.

**CHECK TIRE PRESSURE
BEFORE OPERATING**

FRONT 16 PSI

REAR 10 PSI



GENERAL  ELECTRIC

1. Follow this guide to good performance.

Place tractor on overnight charge **before** using for the first time. Be sure tractor is kept in a fully charged condition at all times. If there is any question turn charger "on" and battery will be automatically charged according to its need.

2. For maximum battery life and performance, the power pack should be "broken in" on a careful schedule as follows:

- A. Charge overnight before first use.

- B. Operate for no more than 1 hour followed by at least 3 hours recharge for first three operations.

- C. Operate for up to 1½ hours followed by at least 4 hours recharge for next three operations.

- D. Always follow fuel level gauge and recharge when empty —
Do not overdischarge.

3. Check water carefully. Do not overfill as spilled electrolyte will eventually weaken battery capacity.

4. Be sure dealer has adjusted tire inflation to proper level.