

**NEW**



# **ELECTRIC TRACTOR PRODUCT INFORMATION**



## **EGT 200**

PRINTED IN U.S.A.



# EGT 200 18 H.P. CLASS ELECTRIC TRACTOR




- 18 H.P. CLASS GARDEN TRACTOR
- FORWARD AND REVERSE ON A SINGLE TOGGLE SWITCH CONTROL
- FOOT PEDAL ACCELERATOR
- FUEL LEVEL GAUGE
- FUEL USAGE GAUGE
- ACCESSORY OUTLET
- HEADLIGHTS AND DASHLIGHT
- FOUR RANGES - 28 SPEEDS FORWARD  
- 12 SPEEDS REVERSE
- DISK BRAKE
- HIGH BACK MOLDED SEAT (ADJUSTABLE)
- BUILT-IN BATTERY CHARGER
- RANGE (Normal Mowing) 3-1/2 HOURS  
4-1/2 HOURS WITH OPTIONAL POWER PACK BOOSTER
- CRUISE CONTROL
- AUTOMOTIVE TYPE STEERING WHEEL
- ELECTRIC LIFT FOR MID MOUNT AND FRONT ATTACHMENTS
- SAFETY FEATURES
  - SEAT SWITCH
  - RETURN TO OFF SYSTEM
  - BRAKE PEDAL SWITCH
- FRONT TIRES 6:50 x 8
- REAR TIRES 10:50 x 12
- NINE M.P.H. MAXIMUM SPEED FORWARD
- POWER PACK 36 VOLT  
(6) SIX VOLT H.D. BATTERIES

## EGT 200 OPERATION


The top of the Avco New Idea Electric Tractor line is represented by the EGT-200 18 horsepower class tractor . . . a truly deluxe Garden Tractor in every respect, with people pleasing features for superb maneuverability, ease of operation, and safety.

As standard equipment, the EGT-200 offers a 'walk on' platform with no center hump to crowd or cramp the operator. Wide foot rests provide plenty of foot and leg room, and a foot pedal accelerator provides complete control of both forward and reverse motion. There is even a 'cruise' control for the utmost in operator convenience and comfort.


The major safety and convenience features of the EGT-200 are described on the following pages. For complete operational and other detailed information, refer to the EGT-200 Operator's Manual (LG-1002).




The operating platform is shown in the picture above. All controls, including the foot pedal accelerator (right) and brake pedal (left) are conveniently located and easily accessible to the operator.



Security and safety are provided by the key switch, which is conveniently located on the tractor console. This switch, when turned clockwise to the 'on' position releases the power from the Power Pack and readies the tractor, attachments, or accessories for instant operation.




The range selector (shown by arrow) provides a selection of four transaxle gear ranges. To change ranges, the foot pedal accelerator must be in the neutral position (foot off of control). For details of usage of each range, refer to EGT-200 Operator's Manual, page 10.



A foot pedal accelerator provides speed control of both forward and reverse motion. The speed of the tractor increases through seven speeds forward or three speeds in reverse as pressure is applied to the foot pedal.




Cruise Control is another exclusive for the EGT-200 and consists of the white push button (upper left) and toggle switch (lower right). Cruise Control locks the tractor into the most efficient operating speed, and may be cancelled either manually or automatically by tripping any one of the tractor safety devices (seat switch, brake switch, etc.)




The forward-reverse toggle switch provides a smooth instant change between forward and reverse tractor motion. The red safety pilot light (lower right) remains on at any time the tractor is in reverse.






An Electric Lift is standard equipment on the EGT-200. It provides fingertip control of both mid mount and front mount attachments.



When the brake pedal is depressed this disk brake goes into action to provide safe sure stops. If the pedal is fully depressed, a brake switch (not shown) provides additional safety by disconnecting power to the tractor drive motor.



Headlights provide plenty of illumination for night mowing or other tasks. Console controls are lighted by a dashlight.



Like all modern power tools, the built-in Power Pack charger is double insulated for safety. Plus it features an automatic shut off when charging is complete. Full power is obtained overnight, 85% in about five hours, and 25% of charge is reached in the first hour of charging.

For proper charger dial settings, refer to page 16 of the EGT-200 Operator's Manual.

---

## Attachments for EGT 200

FOR DETAILS REFER TO LG-3 LAWN AND GARDEN PRODUCT INFORMATION BOOKLET

### MOWERS

42" Mid Mount - Side Discharge	120-0002
42" Mid Mount - Rear Discharge	120-0003
42" Front Mount - Side Discharge	120-0004
42" Front Mount - Rear Discharge	120-0005

### BUNDLE NUMBERS

### OTHER ATTACHMENTS

48" Snow/Dozer Blade	120-0006
Adapter Kit	120-0007
Lawn Sweeper	080-0010
Electric Sweeper Conversion Kit	080-0013
Dump Cart	080-0011
Snow Thrower	100-0003
Adapter Kit	120-0016
Weight Box	120-0013
Front Platform Lift	120-0012
Lift Derrick	120-0018
Extended Range Kit	120-0017
Sleeve Hitch	120-0010
Electric Lift - Rear	120-0011
Manual Lift - Rear	120-0014
P.T.O. Outlet - Rear	150-0002
Front Implement Mounting Bracket	120-0008



## Accessories for EGT 200

FOR DETAILS REFER TO LG-3 LAWN AND GARDEN PRODUCT INFORMATION BOOKLET

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
Electric Horn	120623
Rear Tail Light Kit	120624
36 Volt Power Handle	120628
1/4" Drill Head	120630
Grass Trimmer Head	120633
All Weather Cab	120634
Hitch Adapter	120636
Double Seat	120637
Canopy Top	120638
Golf Bag Holder	120639
Radio Bracket	120640
Inverter	120641
Welder	120642
Welding Kit	120643
Chain Saw	120644
Edger Trimmer	120646
25' DC Extension Cord	120647
Tractor Cover	120655
Measured Battery Filler	120659
Hydrometer (Specific Gravity)	120658

