



DISTRIBUTOR MASTER PARTS PRICE LIST

PARTS LOCATOR SYSTEM

This MASTER PARTS LIST locator has been organized to simplify finding the *price* of the part number you have previously identified from your Product Service Manual or other source. Here's how to do it:

1. Locate the product heading at the top of the page ("Tractor", "Mower", etc.).
2. To find the part number look first for the alphabetical letter (fourth character from the left for each number). Then search numerically. The letters are alphabetical and the numbers are in sequence.
3. With your number located, simply read prices from the columns to the right.

June 1972

GENERAL ELECTRIC COMPANY
OUTDOOR POWER EQUIPMENT OPERATION
CORPORATIONS PARK
SCHENECTADY, NEW YORK 12345

E-8/E-10 TRACTOR PARTS

DESCRIPTION	DWG NO	DIST NET
BEARING	211A3101P2	.85
INSULATOR	211A3165P1	.75
RIVIT	211A3191P1	.15
BELT	211A3226P11	4.25
KNOB	211A3249P3	.50
FUSIBLE LINK	211A3448P2	.85
CLUTCH SWITCH	211A3481P1	3.10
PUSH NUT	211A3488P1	.15
CLEVIS PIN	211A3505P1	.35
CLEVIS PIN	211A3505P14	.10
CLEVIS PIN	211A3505P17	.05
TIMER	211A3507P1	5.80
CAUTION DECAL	211A3511P1	.15
BEARING FLANGED	211A3540P5	.15
CORD ASM	211A3555G1	2.55
SPRING, SEAT	211A3577P1	.45
SPRING, LIFT HANDLE	211A3577P13	.20
SPRING, STEERING	211A3577P16	.20
GROMMET	211A3589P4	.10
TERMINAL KIT	211A3594G2	15.30
PAINT	211A3599P1	2.20
PTO CONTACTOR	243A4524P1	15.95
BATTERY STANDARD	243A4527G1	24.00
SET COLLAR	243A4547P2	.65
KNOB TIMER	243A4549P1	.50
SPACER, LIFT	243A4550P14	.60
SPACER, STEERING	243A4550P17	.55
PUSH NUT	243A4554P3	.05
PLUG P-4	243A4564P3	.25
THRUST WASHER	243A4587P1	.55
CIRC BKR	243A4606P1	7.90
METER ASM	243A4629G1	6.70
RUBBER BUMPER HOOD	243A4639P1	.15
DIODE	243A4652P1	.20
CAPACITOR	243A4653P1	3.00
CAPACITOR	243A4653P2	3.00
STUD	243A4658P1	.30
GREASE-TUBE	243A4680P1	1.50
CIRC BKR	243A4719P1	3.95
SEAT PAN	243A4770P1	8.60
SWITCH, SEAT	243A4790P1	1.60
CAP & MONOGRAM ASM	243A4828G2	.75
BATTERY CAP	243A4849P1	.20
CUSHION BOTTOM	243A4852P1	4.65
GREASE FITTING	243A4867P1	.15
TERMINAL STRIP	243A4953P1	.10
CONTACTOR	244A7063P1	5.75
BUTTON	244A7078P1	1.65
ROD ASM	244A7081G2	3.30
CAP PLUG	244A7102P3	.05
HANDLE GRIP	244A7120P1	.30
BRAKE ROD	244A7126P2	2.40
PAD	244A7159P1	.55
CLEVIS	244A7168P1	1.10
SHAFT & SEG ASM	244A7175G1	9.15

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

E-8/E-10 TRACTOR PARTS

DESCRIPTION	DWG NO	DIST NET
SHAFT & PINION ASM	244A7176G1	4.65
STEERING ARM ASM	244A7180G1	5.35
STEERING ARM	244A7183G1	5.30
LIFT CARLF	244A7185P1	.90
ROLLER	244A7212P3	1.15
REAR WHEEL CLEVIS PIN	244A7221P1	.15
SWITCH-PTO	244A7229P1	1.85
U-BOLT	244A7234P1	.20
BUMPER	244A7262P1	2.20
BELT RETAINER	244A7278G1	3.00
CAPACITOR CLAMP	244A7282P1	.15
BATTERY HOLD DOWN	244A7283P1	2.45
BATTERY HOLD DOWN	244A7283P2	2.45
SHEAVE TRANSAXLE	244A7295P1	3.40
HUB & DISK ASM	244A7301G1	6.20
KEY SWITCH	244A7308P1	2.65
BATTERY PROTECTOR	244A7313P1	.85
BATTERY PROTECTOR	244A7313P2	.85
BATTERY PROTECTOR	244A7313P3	.85
BATTERY PROTECTOR	244A7313P4	.85
BATTERY PROTECTOR	244A7313P5	1.05
BATTERY CI AMP	244A7317P1	3.25
BATTERY CLAMP	244A7317P2	3.25
PULLEY, IDLER	244A7318P1	3.60
SPRING	244A7319P1	.10
SEAT SUPPORT ASM	244A7321G1	4.50
WASHER, STEERING	244A7322P1	.05
DIODE ASM	244A7326G1	1.10
SLEEVE, STEERING	244A7327P1	.15
WIRE 30-01 (CHGR NEG)	244A7334G5	.45
CONNECTION WIRE 1-01	244A7334G9	.50
WIRE (CHGR POS)	244A7334G11	.50
ANGLE	244A7369P1	.60
DECAL TIMER	244A7386P1	.15
DECAL, CORNER RED	244A7389P1	.50
SHEAVE (MOTOR)	244A7392P1	1.90
DECAL GENERAL ELECTRIC	244A7394P1	.15
STRAP	244A7404P1	.45
ARM & BUSHING	244A7407G1	5.30
BRAKE ROD	244A7409P1	2.20
NUT, BRAKE	244A7414P1	.75
SPRING, RETURN	244A7415P1	.70
PIVOT PIN	244A7416P1	1.05
LINE ASM	244A7424G1	.25
ACCESS OUTLET S0-2	244A7436G1	3.20
ACCESS OUTLET S0-2	244A7436G2	3.20
CABLE CLIP	244A7438P1	.05
TRIM	244A7448P1	.55
HAND GRIP	244A7466P1	.05
PARKING BRAKE DECAL	244A7471P1	.20
COVER	247A7307G1	2.85
BATTERY COVER	247A7308G1	2.65
KEY	247A7354P1	.80
HEAT SINK	163B9905G1	6.15
TRANSFORMER	163B9955P1	60.50
CUSHION REAR	178B8030P1	12.90

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

E-8/E-10 TRACTOR PARTS

DESCRIPTION	DWG NO	DIST NET
AXLE-FRONT	178B8032P1	25.60
LIFT HANDLE ASM	178B8134G2	15.85
TRANSFORMER	178B8146P1	43.00
BATT CABLE	178B8165G1	1.90
BATTERY CABLE	178B8165G7	1.25
BATT CABLE	178B8165G8	3.10
BATT CABLE	178B8165G10	1.90
BATT CABLE	178B8165G11	4.50
MOWER LIFT ARM ASM	178B8176G1	9.00
ROD, TIE	178B8203P1	4.05
ROD, TIE	178B8203P2	3.70
MOTOR-DRIVE, E8	178B8216P1	93.75
SPINDLE	178B8217G1	7.65
HOOD ASM	178B8223G1	14.00
STANDARD BATTERY 12V	178B8236P1	25.00
HANDLE, PARKING BRAKE	178B8237P1	1.85
TIMER ASM	178B8238G1	9.55
MOTOR DRIVE, F10	178B8244P1	105.00
EXTEN. CABLE	178B8246G1	3.90
SEAT HOUSING ASM	178B8252G1	15.35
DECAL, CORNER BLACK	178B8261P1	.15
TORQUE PLATE	178B8262G1	7.80
BATTERY CLAMP RIGHT	178B8263P1	2.75
BATTERY CLAMP LEFT	178B8263P2	2.75
SHIFTING DECAL	178B8267P1	.20
DECAL, E8M	178B8269P1	.20
DECAL E10M	178B8270P1	.20
ARM & SHAFT ASM	178B8278G1	6.15
SPINDLE	178B8282G1	7.65
PEDAL ASM	178B8283G1	3.55
TRAY, BATT	155C8094P1	2.45
BULKHEAD	155C8100P1	2.90
CHARGER BASE	155C8103P1	4.25
LIFT QUADRANT ASM	155C8106P1	3.20
TIRE-WHL ASM FR	155C8121G1	14.90
TIRE-WHL ASM FR	155C8121G2	15.90
LINER	155C8122P1	.75
TIRE-WHL ASM RR	155C8125G1	20.90
BELT GUARD	155C8126P1	2.40
TIRE-WHL ASM RR	155C8131G1	25.90
DASH HARNESS	155C8132G1	1.45
CONTROL PANEL HARNESS	155C8134G1	10.50
DASH HARNESS	155C8136G1	2.20
STEERING SHAFT SUPPORT	155C8141P1	3.80
MOTOR COMP. COVER	155C8142P1	3.50
COVER, BELT	155C8147P1	2.65
BRAKE ASM	155C8149G1	7.25
INSTRUCTION DECAL	155C8167P1	.35
DASH HARNESS	155C8178G1	2.20
TRANSAXLE	127D8015P1	125.00
DASH COMPARTMENT	127D8019P1	14.30
DASH COMPARTMENT	127D8019P2	14.10
STEERING WHEEL	127D8023P1	9.40
CHARGER SUB ASSEMBLY	127D8024G3	59.50
CHARGER SUB ASM	127D8024G4	74.50
FRONT GRILLE	127D8033P1	7.05

PRICES SUBJECT TO CHANGE WITHOUT NOTICE

